

Sponsor: Martin Werneholm Airinum AB c/o Ahouse Ostermalmsgatan 26A Stockholm, 114 26 **SWEDEN**

Viral Filtration Efficiency (VFE) Final Report

Test Article:

Optimal Filter

Purchase Order:

AIR0001

Study Number: 1324843-S01A.1 Amended

Study Received Date: 27 Jul 2020

Study Completion Date: 27 Aug 2020

Testing Facility:

Nelson Laboratories, LLC

6280 S. Redwood Rd.

Salt Lake City, UT 84123 U.S.A.

Test Procedure(s): Deviation(s): Standard Test Protocol (STP) Number: STP0007 Rev 16

None

Summary: The VFE test is performed to determine the filtration efficiency of test articles by comparing the viral control counts upstream of the test article to the counts downstream. A suspension of bacteriophage Φ X174 was aerosolized using a nebulizer and delivered to the test article at a constant flow rate and fixed air pressure. The challenge delivery was maintained at 1.1 - 3.3 x 10³ plague forming units (PFU) with a mean particle size (MPS) of 3.0 um ± 0.3 um. The aerosol droplets were drawn through a six-stage, viable particle, Andersen sampler for collection. The VFE test procedure was adapted from ASTM F2101.

All test method acceptance criteria were met. Testing was performed in compliance with US FDA good manufacturing practice (GMP) regulations 21 CFR Parts 210, 211 and 820.

Test Side: Black Nonwoven Side

Test Area: ~40 cm²

VFE Flow Rate: 28.3 Liters per minute (L/min)

Conditioning Parameters: 85 ± 5% relative humidity (RH) and 21 ± 5°C for a minimum of 4 hours

Positive Control Average: 1.6 x 103 PFU

Negative Monitor Count: <1 PFU

MPS: 2.7 µm

Study Director

801-290-7500

James W. Luskin



1324843-S01

nelsonlabs.com

sales@nelsonlabs.com

FRT0007-0001 Rev 16

Page 1 of 2



Results:

Test Article Number	Percent VFE (%)
1	>99.9ª
2	>99.9ª
3	>99.9ª
4	>99.9ª
5	>99.9ª

^a There were no detected plagues on any of the Andersen sampler plates for this test article.

The filtration efficiency percentages were calculated using the following equation:

$$\% VFE = \frac{C - T}{C} \times 100$$

C = Positive control average

T = Plate count total recovered downstream of the test article Note: The plate count total is available upon request

Amendment Justification: At the request of the sponsor, the initial report was separated into individual reports by test article. Additionally, the test article was changed from "Filter" to "Optimal Filter", "Filter + Skin" to "Urban Air Mask 2.0", and "Skin" to "Urban Air Mask 2.0 - Skin".

801-290-7500